



- 1 - TO PCOAT RENDER
- 2 - REINFORCEMENT LAYER (MESH AND ADHESIVE)
- 3 - EPS PLATINUM BOARD
- 4 - ANGLE CORNER BEAD
- 5 - REVEAL INSULATION (20-30MM)
- 6 - WINDOW REVEAL BEAD (6436)
- 7 - EXTERNAL WINDOW SILL

KREISEL®



MODERN.INSULATION.SYSTEMS