



MW Wind Zone 1



\* Sold line at left edge represents the end of the wall; the dotted line at the top, bottom and right edge, represents a continuous wall

\*\*The box represents an opening (ie. window/door)


MW Wind Zone 2



\* Sold line at left edge represents the end of the wall; the dotted line at the top, bottom and right edge, represents a continuous wall

\*\*The box represents an opening (ie. window/door)


MW Wind Zone 3



\* Sold line at left edge represents the end of the wall; the dotted line at the top, bottom and right edge, represents a continuous wall

\*\*The box represents an opening (ie. window/door)


MW Wind Zone 4



\* Sold line at left edge represents the end of the wall; the dotted line at the top, bottom and right edge, represents a continuous wall

\*\*The box represents an opening (ie. window/door)

MW Wind Zone 5



\* Sold line at left edge represents the end of the wall; the dotted line at the top, bottom and right edge, represents a continuous wall

\*\*The box represents an opening (ie. window/door)